Quick Start Guide

skeye.pos mobile

HW 90396

Views and Functions







Contact:

Höft & Wessel AG
Skeye
Rotenburger Str. 20
30659 Hannover

Phone. +49 511 6102 0
Fax. +49 511 6102 411
Mail. info@skeye.com
Web. www.skeye.de
Serviceline. +49 1803 232829 (0.09 EUR per min. within Germany)

Version 1.1

skeye.

by Höft & Wessel

www.skeye.com

Inserting a SIM Card

If your devices supports the "GRRS/GSM" option, you have to insert a SIM card of your provider to be able to use this function.

- Press the yellow button to switch off the skeye.pos mobile.
- Remove the battery.
- Press the battery eject button while pulling the security module out of the mobile terminal by applying **light** pressure on the recessed grip.
- Located on one side of the security module slot is a SIM card slot.



- Slide the SIM card with the chip pointing down into the card slot. Press to engage the card.
- Install the security module.
- Insert the battery and lock.

Inserting/Changing the Battery

Please note:
Prior to operation, the storage battery of the device (placed in desktop cradle) has to be loaded.



- Slide the battery lock to the left to this symbol:
- Place a charged battery with the rounded side facing downwards.
- Fold the battery downwards and press it into place.
- Slide the battery lock to the right to this symbol:
  The battery is now locked and you can switch on the skeye.pos mobile.

  In case of a long-term storage, the skeye.pos mobile changes to "Complete Off" to preserve the floating battery.

  If the skeye.pos mobile is in "Complete Off" mode, it **cannot** be switched on using the yellow button. In this case, a **Reset** has to be triggered on the device.

Switching on the device

Use the yellow button to switch the device on or off.

Reset

The purpose of the reset function is to **cancel** the running/hanging user program at any point.

Press the reset button carefully with very little effort. Use a long thin object such as a straightened paper clip.

Desktop Cradle

LEDs
red – green – yellow
Connection to the skeye.pos mobile
Hook to engage the skeye.pos mobile
ALMEX
Lever to unlock the skeye.pos mobile

Placing the skeye.pos mobile

Please note:
Make sure that you place the skeye.pos mobile on the desktop cradle with a battery fitted and locked in place. Otherwise, the skeye.pos mobile cannot be switched on.

- Position the skeye.pos mobile over the desktop cradle so that the plug-type connection for the desktop cradle and the two attachment slots for the clips are precisely aligned .
- Press the skeye.pos mobile in the middle of the device above and below the display to engage it into the desktop cradle.
- To remove the device from the desktop cradle is has to be unlocked using the respective lever.